

Part # = 43082-1062

Part Description = BRAKE PAD ASSEMBLY

Model Count = 176

EX250-E1	86	250	NINJA 250R	SPORTBIKE
EX250-E1L	86	250	NINJA 250R (CAL)	SPORTBIKE
EX250-E2	87	250	NINJA 250R	SPORTBIKE
EX250-E2L	87	250	NINJA 250R (CAL)	SPORTBIKE
EN450-A1	85	450	454 LTD	LTD STREET
EN450-A1L	85	450	454 LTD (CAL)	LTD STREET
EN450-A2	86	450	454 LTD	LTD STREET
EN450-A2L	86	450	454 LTD (CAL)	LTD STREET
EN450-A3	87	450	454 LTD	LTD STREET
EN450-A3L	87	450	454 LTD (CAL)	LTD STREET
EN450-A4	88	450	454 LTD	LTD STREET
EN450-A4L	88	450	454 LTD (CAL)	LTD STREET
EN450-A5	89	450	454 LTD	LTD STREET
EN450-A5L	89	450	454 LTD (CAL)	LTD STREET
EN450-A6	90	450	454 LTD	LTD STREET
EN450-A6L	90	450	454 LTD (CAL)	LTD STREET
EN500-A4	93	500	VULCAN 500	CRUISER
EN500-A4L	93	500	VULCAN 500 (CAL)	CRUISER
EN500-A5	94	500	VULCAN 500	CRUISER
EN500-A5L	94	500	VULCAN 500 (CAL)	CRUISER
EN500-A6	95	500	VULCAN 500	CRUISER
EN500-A6L	95	500	VULCAN 500 (CAL)	CRUISER
EN500-A7	96	500	VULCAN 500	CRUISER
EN500-A7L	96	500	VULCAN 500 (CAL)	CRUISER
ZX600-A1	85	600	NINJA 600R	SPORTBIKE
ZX600-A1L	85	600	NINJA 600R (CAL)	SPORTBIKE
ZX600-A2	86	600	NINJA 600R	SPORTBIKE
ZX600-A2L	86	600	NINJA 600R (CAL)	SPORTBIKE
ZX600-A3	87	600	NINJA 600R	SPORTBIKE
ZX600-B1	87	600	NINJA 600RX	SPORTBIKE
ZX600-B1L	87	600	NINJA 600RX (CAL)	SPORTBIKE
VN700-A1	85	700	VULCAN 700	CRUISER
VN700-A1L	85	700	VULCAN 700 (CAL)	CRUISER
ZN700-A1	84	700	700 LTD SHAFT	LTD STREET
ZN700-A1L	84	700	700 LTD SHAFT (CAL)	LTD STREET
ZN700-A2	85	700	700 LTD SHAFT	LTD STREET
ZN700-A2L	85	700	700 LTD SHAFT (CAL)	LTD STREET
VN750-A10	94	750	VULCAN 750	CRUISER
VN750-A10L	94	750	VULCAN 750 (CAL)	CRUISER
VN750-A11	95	750	VULCAN 750	CRUISER
VN750-A11L	95	750	VULCAN 750 (CAL)	CRUISER
VN750-A12	96	750	VULCAN 750	CRUISER
VN750-A12L	96	750	VULCAN 750 (CAL)	CRUISER
VN750-A13	97	750	VULCAN 750	CRUISER
VN750-A13L	97	750	VULCAN 750 (CAL)	CRUISER
VN750-A14	98	750	VULCAN 750	CRUISER
VN750-A14L	98	750	VULCAN 750 (CAL)	CRUISER
VN750-A15	99	750	VULCAN 750	CRUISER
VN750-A15L	99	750	VULCAN 750 (CAL)	CRUISER
VN750-A16	2000	750	VULCAN 750	CRUISER
VN750-A16L	2000	750	VULCAN 750 (CAL)	CRUISER
VN750-A2	86	750	VULCAN 750	CRUISER
VN750-A2L	86	750	VULCAN (CAL)	CRUISER
VN750-A3	87	750	VULCAN 750	CRUISER
VN750-A3L	87	750	VULCAN 750 (CAL)	CRUISER
VN750-A4	88	750	VULCAN 750	CRUISER
VN750-A4L	88	750	VULCAN 750 (CAL)	CRUISER
VN750-A5	89	750	VULCAN 750	CRUISER
VN750-A5L	89	750	VULCAN 750 (CAL)	CRUISER
VN750-A6	90	750	VULCAN 750	CRUISER
VN750-A6L	90	750	VULCAN 750 (CAL)	CRUISER
VN750-A7	91	750	VULCAN 750	CRUISER
VN750-A7L	91	750	VULCAN 750 (CAL)	CRUISER
VN750-A8	92	750	VULCAN 750	CRUISER
VN750-A8L	92	750	VULCAN 750 (CAL)	CRUISER
VN750-A9	93	750	VULCAN 750	CRUISER
VN750-A9L	93	750	VULCAN 750 (CAL)	CRUISER
ZX750-E1	84	750	GPz750 TURBO	SUPERBIKE
ZX750-E1L	84	750	GPz750 TURBO (CAL)	SUPERBIKE
ZX750-E2	85	750	GPz750 TURBO	SUPERBIKE
ZX750-E2L	85	750	GPz750 TURBO (CAL)	SUPERBIKE

Part # = 43082-1062

Part Description = BRAKE PAD ASSEMBLY

Model Count = 176

ZL900-A1	85	900	ELIMINATOR 900	PERFORMANCE CRUISER
ZL900-A1L	85	900	ELIMINATOR 900 (CAL)	PERFORMANCE CRUISER
ZL900-A2	86	900	ELIMINATOR 900	PERFORMANCE CRUISER
ZL900-A2L	86	900	ELIMINATOR 900 (CAL)	PERFORMANCE CRUISER
ZG1000-A1	86	1000	CONCOURS	TOURING
ZG1000-A1L	86	1000	CONCOURS (CAL)	TOURING
ZG1000-A10	95	1000	CONCOURS	TOURING
ZG1000-A10L	95	1000	CONCOURS (CAL)	TOURING
ZG1000-A12	97	1000	CONCOURS	TOURING
ZG1000-A12L	97	1000	CONCOURS (CAL)	TOURING
ZG1000-A13	98	1000	CONCOURS	TOURING
ZG1000-A13L	98	1000	CONCOURS (CAL)	TOURING
ZG1000-A14	99	1000	CONCOURS	TOURING
ZG1000-A14L	99	1000	CONCOURS (CAL)	TOURING
ZG1000-A15	2000	1000	CONCOURS	TOURING
ZG1000-A15L	2000	1000	CONCOURS (CAL)	TOURING
ZG1000-A2	87	1000	CONCOURS	TOURING
ZG1000-A2L	87	1000	CONCOURS (CAL)	TOURING
ZG1000-A3	88	1000	CONCOURS	TOURING
ZG1000-A3L	88	1000	CONCOURS (CAL)	TOURING
ZG1000-A5	90	1000	CONCOURS	TOURING
ZG1000-A5L	90	1000	CONCOURS (CAL)	TOURING
ZG1000-A6	91	1000	CONCOURS	TOURING
ZG1000-A6L	91	1000	CONCOURS (CAL)	TOURING
ZG1000-A7	92	1000	CONCOURS	TOURING
ZG1000-A7L	92	1000	CONCOURS (CAL)	TOURING
ZG1000-A8	93	1000	CONCOURS	TOURING
ZG1000-A8L	93	1000	CONCOURS (CAL)	TOURING
ZG1000-A9	94	1000	CONCOURS	TOURING
ZG1000-A9L	94	1000	CONCOURS (CAL)	TOURING
ZL1000-A1	87	1000	ZL1000	PERFORMANCE CRUISER
ZL1000-A1L	87	1000	ZL1000 (CAL)	PERFORMANCE CRUISER
ZX1000-A1	86	1000	NINJA 1000R	SPORTBIKE
ZX1000-A1L	86	1000	NINJA 1000R (CAL)	SPORTBIKE
ZX1000-A2	87	1000	NINJA 1000R	SPORTBIKE
ZN1100-B1	84	1100	1100 LTD SHAFT	LTD STREET
ZN1100-B1L	84	1100	1100 LTD SHAFT (CAL)	LTD STREET
ZN1100-B2	85	1100	1100 LTD SHAFT	LTD STREET
ZN1100-B2L	85	1100	1100 LTD SHAFT (CAL)	LTD STREET
ZG1200-A1	86	1200	VOYAGER XII	TOURING
ZG1200-A1L	86	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B1	87	1200	VOYAGER XII	TOURING
ZG1200-B1L	87	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B10	96	1200	VOYAGER XII	TOURING
ZG1200-B10L	96	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B11	97	1200	VOYAGER XII	TOURING
ZG1200-B11L	97	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B12	98	1200	VOYAGER XII	TOURING
ZG1200-B12L	98	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B13	99	1200	VOYAGER XII	TOURING
ZG1200-B13L	99	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B14	2000	1200	VOYAGER XII	TOURING
ZG1200-B14L	2000	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B2	88	1200	VOYAGER XII	TOURING
ZG1200-B2L	88	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B3	89	1200	VOYAGER XII	TOURING
ZG1200-B3L	89	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B4	90	1200	VOYAGER XII	TOURING
ZG1200-B4L	90	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B5	91	1200	VOYAGER XII	TOURING
ZG1200-B5L	91	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B6	92	1200	VOYAGER XII	TOURING
ZG1200-B6L	92	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B7	93	1200	VOYAGER XII	TOURING
ZG1200-B7L	93	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B8	94	1200	VOYAGER XII	TOURING
ZG1200-B8L	94	1200	VOYAGER XII (CAL)	TOURING
ZG1200-B9	95	1200	VOYAGER XII	TOURING
ZG1200-B9L	95	1200	VOYAGER XII (CAL)	TOURING
VN1500-A1	87	1500	VULCAN 88	CRUISER

Part # = 43082-1062

Part Description = BRAKE PAD ASSEMBLY

Model Count = 176

VN1500-A1L	87	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A10	96	1500	VULCAN 1500	CRUISER
VN1500-A10L	96	1500	VULCAN 1500 (CAL)	CRUISER
VN1500-A11	97	1500	VULCAN 1500	CRUISER
VN1500-A11L	97	1500	VULCAN 1500 (CAL)	CRUISER
VN1500-A12	98	1500	VULCAN 1500	CRUISER
VN1500-A12L	98	1500	VULCAN 1500 (CAL)	CRUISER
VN1500-A13	99	1500	VULCAN 1500	CRUISER
VN1500-A13L	99	1500	VULCAN 1500 (CAL)	CRUISER
VN1500-A2	88	1500	VULCAN 88	CRUISER
VN1500-A2L	88	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A3	89	1500	VULCAN 88	CRUISER
VN1500-A3L	89	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A4	90	1500	VULCAN 88	CRUISER
VN1500-A4L	90	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A5	91	1500	VULCAN 88	CRUISER
VN1500-A5L	91	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A6	92	1500	VULCAN 88	CRUISER
VN1500-A6L	92	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A7	93	1500	VULCAN 88	CRUISER
VN1500-A7L	93	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A8	94	1500	VULCAN 88	CRUISER
VN1500-A8L	94	1500	VULCAN 88 (CAL)	CRUISER
VN1500-A9	95	1500	VULCAN 88	CRUISER
VN1500-A9L	95	1500	VULCAN 88 (CAL)	CRUISER
VN1500-B1	87	1500	VULCAN 88 SE	CRUISER
VN1500-B1L	87	1500	VULCAN 88 SE (CAL)	CRUISER
VN1500-B2	88	1500	VULCAN 88 SE	CRUISER
VN1500-B2L	88	1500	VULCAN 88 SE (CAL)	CRUISER
VN1500-B4	90	1500	VULCAN 88 SE	CRUISER
VN1500-B4L	90	1500	VULCAN 88 SE (CAL)	CRUISER
VN1500-C3	96	1500	VULCAN 1500 L	CRUISER
VN1500-C3L	96	1500	VULCAN 1500 L (CAL)	CRUISER
VN1500-C4	97	1500	VULCAN 1500 L	CRUISER
VN1500-C4L	97	1500	VULCAN 1500 L (CAL)	CRUISER

Page - 3